

Model: S-Cape Hand Wand

Capabilities

Programmable position
Set position
Preset Position One, Two, and Three
Head Up
Head Down
Foot Up
Foot Down
Head Massage On/Off
Head Massage Increase
Head Massage Decrease
Foot Massage On/Off
Foot Massage Increase
Foot Massage Decrease
Wave Massage On/Off
Wave Massage Increase
Wave Massage Decrease
Level

Functions

Massage System

2 motor, variable speed,
30-Minute timer.

The normal operation of the massage system is to automatically start the motor on high speed and then change to the last recorded speed of the massage motor.

Wave features variable speed rolling massage.



Hand Wand

Wireless
Backlit
Requires four AAA batteries.

Auto learn feature:

Press position one button and head massage on/off button simultaneously for 10 seconds. Make sure all other beds are unplugged with only learning bed plugged in.

To program your favorite position and massage:

1. Take the bed to your desired setting.
2. Hold the set position button for 5 seconds.
3. Press the  button for 5 seconds.
4. To return to the desired setting press the  button.

Preset position one, two and three take you to the pictured position.

